Bushnell®

7 DAY WIRELESS FORECASTER
WEATHERFX

Quick Start Guide

Weather FXi Quick Start Guide

Step 1: Install the Software

Insert the CD, click the "Weather FXi Setup Wizard" button and follow the onscreen directions to install the Weather FXi software on your PC *(Windows 2000 or later, with an "always on" internet connection).*

Step 2: Connect the Transmitter

Connect the USB Transmitter to your PC's USB port.

Step 3: Start the Weather FXi application, Set Locations and Units

Double click the "Weather FXI" icon on your desktop. When the application opens, click in the first, far left box (in the top row of five), then click the blue "Edit Location" box when it appears (*3a*). Set your current location by selecting from the four drop down lists, then click "Save" to store this "Home" location (*3b*). Follow the same process to setup any or all of the remaining four location boxes for other cities. Next, click the "Settings" button and set your preferences for temperature, wind speed units and time format, then click "Save" (*3c*). In the main Weather FXi application window, you can click in any of the other "location boxes" you set up to see the forecast for that city.

1

Install the Software

2

Connect the Transmitter

3

Start Weather FXi App, Set Locations & Units

3a

Edit (Home) Location

3b

Settings (Set Units)

3c

Weather FXi Quick Start Guide

Step 4: Setup the Receiver Unit (LCD Display)

Insert 4x AA batteries into the Receiver, or connect its supplied AC adapter. The Receiver's display initializes and reads "Searching for PC" *(press the* **SEARCH** *button on the back of the unit if this does not appear).* Attach the easel stand to the Receiver and place it near your PC so you can see its display while you complete the setup.

Step 5: Transmit Weather Data from the PC Application to the Receiver

Click "Send to Receiver" on the Weather FXi program window (*5a*) to transmit data from the PC software to the Receiver. The Receiver will indicate "PC FOUND-PLS WAIT 5 MINS" When the Transmitter's light stops flashing, check to see that the Receiver's display matches the weather data shown on the PC screen (use the +/- buttons on the Receiver to change locations). Press **UNITS** on the back of the Receiver to change the units if necessary, using the +/- buttons. Press **UNITS** again to change other displayed units.

Keep the Weather FXi application running in the background and keep your PC powered on and connected to the internet, so the Receiver can provide you with the latest up-to-date forecast information.

AC Adapter Jack

Stand Keyhole

SEARCH   BRIGHTNESS

UNITS

4   **Setup the Receiver**

SEARCH button

UNITS button

SEARCH   BRIGHTNESS

UNITS

5

Transmit Data from PC to Receiver

5a

BACKLIGHT COLOR REFERENCE :
Temperature Range

Cold 30s 40s 50s 60s 70s 80s Hot

Button / Controls Reference

| Button Location	#/ Name	Function
Back of Unit	*1)* **SEARCH**	Initiates search for PC -puts receiver on standby to receive data from USB transmitter
Back of Unit	*2)* **UNITS**	Press (repeatedly) to select hour format, wind speed and temperature units (use +/- to change setting)
Back of Unit	*3)* **BRIGHTNESS**	Press to select backlight brightness level (High, Low or Off)
Top of USB Transmitter	*4)* **TRANSMIT**	Equivalent to clicking "Send to Receiver" in Weather FXi software window
Front of Unit	*5)* **+ and -**	Press to select Favorite Locations and to increment/decrement various settings
Top of Unit	*6)* **SNOOZE/ BACKLIGHT**	Press to turn backlight on for few seconds. If alarm is sounding, press for snooze function (alarm resounds after 9 minutes)
Top of Unit	*7)* **ALARM**	Turns alarm on/off
Top of Unit	*8)* **AL SET**	Press to set the alarm time (use +/- to change setting)
Front of Unit	*9)* **Today, Day 2, etc**	Displays morning, afternoon and evening forecasts for the selected day. Press & hold "Day 4" to view forecast for 5, 6 and 7.

**USB Transmitter**

Back of Receiver

Button / Controls Reference

6   **7**   **8**

Bushnell

SIGNAL ▪▪▪	FAVORITE ◎
12:32 PM	BOSTON
CURRENTLY	TODAY
32°	33°
	HI / 24°
RealFeel® 22°	
	INDOOR 70°

5

HEAVY SNOW ALL DAY 18 IN.

HUMIDITY	PRECIPITATION	WIND	UV INDEX
9 %	96 %	15 mph	0

TUES	32° HI / LO 18°
WED	36° HI / LO 22°
THUR	43° HI / LO 27°

Today

Day 2

Day 3

Day 4
5-7

9

Forecast Icons Reference

Sunny

Mostly Sunny/Hazy

Partly Sunny

Cloudy

Partly Sunny w/Showers

Partly Sunny w/Thundershowers

Mostly Cloudy w/Showers

Rain

Thunderstorms

Partly Sunny w/Flurries

Flurries

Wintery Mix

Snow

Clear (night)

Partly Cloudy (night)

Partly Cloudy w/Showers (night)

Partly Cloudy w/Thundershowers (night)

Bushnell®
OUTDOOR
TECHNOLOGY

INNOVATION THAT THRIVES OUTSIDE

For further questions or additional information please contact:

Bushnell Outdoor Products
9200 Cody, Overland Park, Kansas 66214
(800) 423-3537 • www.bushnell.com